



# GATESLAVE SMS INSTRUCTIONS

**GATESLAVE SMS INSTRUCTIONS – ALL THESE FEATURES ARE MORE EASILY ACCESSED FROM YOUR WEB PAGE – JUST LOG ON WITH YOUR ID / LOGON e.g. -DW345Z**

This will be updated as features change or are added to. Check with your Distributor or our website for the most up to date information.

**SMS / Text can be used if a PC / Internet is not available- or send an e mail or phone our technical people direct for assistance. These commands work from any phone.**

**The user has a default PIN of 1234  
The codes below assume this has not been changed.**

**Xuuuu** Forces an update from the web site- immediately.

Even though you make the changes to a GateSlave on your personal web page and press “save and update” the actual Gate will be told by the system later when it checks in – if you send an Xuuu SMS you are telling the Gate that there are new details and that it must check with the servers at once.

**X1234p5678** Changes user PIN from 1234 to 5678

**X1234go** Opens and holds open the gate- providing gate is set up for this

**X1234gc** Closes the gate if previously sent a X1234go

\*You must make sure to send the gate a X1234gc after a X123go unless you wish the gate to stay open indefinitely.

**X1234gp** Open pulse to gate version 3.5 onwards.

**X1234R** Force a device reset Version 2.3 onwards-  
(Always after a reset make sure to send an Xuuuu- after 10 mins! )Used to reset a unit remotely.

**X1234tw** Download a full week of timed data Version 3.0 on  
Your Gateslave is capable when set by your installer of opening and closing using our unique on line clock – program your gate on line to open /close at different times and different days. After setting the times up on the website you can send the gate a text to ask it to download the next weeks settings in one go. If you dont do this the gate will learn the settings over the first week.

**X1234s** Get a status for a Gateslave returned to calling phone Version 3.5 onwards.

**VIP to check if SIM is in credit,most problems are because of NO CREDIT  
GATES will continue to operate but Timers and UPDATES will fail.  
We can provide a Contract SIM see our Website – no more Top Ups  
If SIM has run out of Credit – Only Credit 10 E each time**

This is a very useful feature as it tells you how your gate is – and what the settings are ! If its open or closed – if its timed enabled – if its alarm enabled etc – see website or e mail [info@vvstechnology](mailto:info@vvstechnology) for full technical brochure

Technical Support is only a phone call or e mail to our Ireland or UK Technical support team.

Ireland +353(0) 872558510

UK +44 (0)1414165533

e mail for fast response- [info@vvstechnology.com](mailto:info@vvstechnology.com)

[www.gateslave.com](http://www.gateslave.com)

[www.heatslave.com](http://www.heatslave.com)

[www.cltcameras.com](http://www.cltcameras.com)

All products are EU products and are designed and manufactured by VVS .

### **LED SEQUENCE on Start UP /Diagnostics**

Green- for 4 seconds

Flashing Red Led – Looking for SIM

Solid Red LED – SIM Found logging on to Cell

Red + Green – Cell found Setting for Data

Amber – Looking for Data Slot from Network

Amber + Green – Found Data slot connecting to Website

Amber + Red – Found Website and Downloading Data

Amber – ONLY on timed units , downloading Time of Day.

Solid Green – Ready for Operation.

Red Amber Green Flashing – Needs Service Call – Contact Installer.

Red and Green Solid On – Gate is in timed mode and GATE is open

- MAKE SURE TO HAVE YOU UNIQUE GATESLAVE LOGIN/ID WHEN YOU CALL  
THAT YOU HAVE CREDIT ON SIM BEFORE CALLING

+ CHECK

**VIP to check if SIM is in credit,most problems are because of NO CREDIT  
GATES will continue to operate but Timers and UPDATES will fail.  
We can provide a Contract SIM see our Website – no more Top Ups  
If SIM has run out of Credit – Only Credit 10 E each time**